



How should I specify the FERO Break-Away™ Fire-Release Connectors?

We typically see our connectors in the metals/structural steel section. Suggested spec:

FERO Break-Away™ Fire-Release Connectors

- 1. Manufactured by FERO Corporation in Edmonton, Alberta, Canada.
 - a. Slotted steel support angle with fusible nylon washer against a grooved edge
 - b. Size:
 - i. Steel support with dimensions, configuration, and spacing as indicated on drawings

On drawings, we suggest labelling the connectors as:

FERO Break-AwayTM Fire-Release Single/ Dual/ Angle, Standard/ Inverted Connector: L x W x H - T (or angle size), spaced x in.